USER MANUAL

RN 1500
LED LIGHT

Thank you for purchasing this Olight Product. Please read this manual carefully before use and keep it for future reference!

IN THE BOX



RN 1500

Handlebar mount

3mm Hex

Gopro mount



Aero bar compatible strap



Type-C USB Cable

SPECIFICATIONS

LUMENS/RUN TIME



164m	6700cd	1m	IPX7

(L)4.21 x (D)1.22in (L)107 x (D)31mm	172g / 6.08oz

All performance measurements in accordance with ANSI/NEMA FL1-2009 standards.The tests are performed using the battery included in the LED light, and is measured indoors under a room temperature of 25 degrees Celsius with windless conditions.

The runtime may vary depending on the external temperature and ventilation conditions, these biases may affect the results of testing.

HOW TO RECHARGE

Charging

FLASH RED

Fully charged

GREEN



Standard charging time
Approx.2.5hrs (5V 3A)

BATTERY INDICATOR

When the device is power-on, the power button light will indicatethe battery level.

When the device is power-off, short press the power button to activate the indicator light (light will shut down automatically after 2 seconds).



GREEN
100%-21%

RED
20%-11%

FLASH RED
10%-0%



PHONE CHARGING INSTRUCTION



(5V 2.4A)

DANGER

- DO NOT throw the light directly into human eyes. This may cause temporary blindness, or permanent damage to the eyes.
- DO NOT cover the light head when the LED light is on, or place the LED light head on the ground. The radiation energy of the LED light may cause damage to the LED light itself, or even result in burming to flammable objects.

WARNING

- Keep out of reach of children.
- The light contains a lithium-ion battery. Certain restrictions may apply to this product when traveling, especially when traveling by air. Always check with your carrier for specific restrictions prior to traveling with this product.

NOTICE

Store the light at room temperature in a dry place. Avoid moisture, or extreme hot or cold.

Store the light in the charged condition. Avoid “deep discharge." Battery life will decrease if the light is stored in a fully discharged condition.

Over time, the run time of the battery will diminish. Expect about 500 full charges, depending on care. After a full life, the battery will continue to charge but with a lower run time.

When the run time is unsatisfactory, please recycle. Do not open the case of the light or incinerate.

CONTENTS

(EN) English _ _ _ _ _ _ _ _ _ _ _ _ _ _ 01
(CHS) 简体中文 _ _ _ _ _ _ _ _ _ _ _ _ _ _ 01
(NED) Nederland _ _ _ _ _ _ _ _ _ _ _ _ 01
(DE) Deutsch _ _ _ _ _ _ _ _ _ _ _ _ _ _ 02
(JP) 日本語 _ _ _ _ _ _ _ _ _ _ _ _ _ _ 02
(FR) Français _ _ _ _ _ _ _ _ _ _ _ _ _ 02
(IT) Italia _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ 02

(EN) English

HOW TO OPERATE

Long press to turn on/off the light, click to change the brightness level and flash modes, and double click to swith modes. Mode memory function will save the last selected mode and brightness.

(CHS) 简体中文

如何操作

长按开机/关机，单击切换不同亮度或闪烁方式，双击切换不同模式。再次开机进入上次关机时的模式及亮度。

(NED) Nederland

HOE TE BEDIENEN

Druk lang om het licht aan/uit te zetten, klik om het helderheidsniveau en de flits modi te veranderen en dubbelklik om tussen de modi te schakelen. De modus geheugenfunctie zal de laatst geselecteerde modus en helderheid opslaan.

(DE) Deutsch

BEDIENUNG

Gedrückt halten, um das Licht ein-/auszuschalten. Kurz Anklicken zum Umschalten der Helligkeitsstufe und Blitzmodi und Doppelklicken zum Umschalten der Modi. Die Modus-Speicherfunktion wird den zuletzt ausgewählten Modus und die Helligkeitsstufe speichern.

(JP) 日本語

使用方法

ON/OFFランプを長く押して、クリックして輝度のレベルとフラッシュモデルを変更し、ダブルクリックしてSWITHモデルに切り替えます。モデルメモリ機能が最後のモデルと輝度の記録を残ります。

(FR) Français

COMMENT L'UTILISER

Appuyez longuement pour allumer/éteindre la lumière, cliquez pour changer le niveau de luminosité et les modes de flash, et double-cliquez pour basculer d'un mode à l'autre. La fonction de mémoire de mode enregistre le dernier mode et la dernière luminosité sélectionnés.

(IT) Italia

FUNZIONAMENTO

Premere a lungo per accendere / spegnere la luce, cliccare per modificare il livello di luminosità e le modalità flash e fare doppio clic per cambiare modalità. La funzione di memorizzazione della modalità salverà l'ultima modalità e luminosità selezionate.

WARRANTY

Within 30 days of purchase: Return to the original seller for repair or replacement.

Within 2 years of purchase: Return to Olight for repair or replacement. This warranty does not cover normal wear and tear, modifications, misuse, disintegrations, negligence, accidents, improper maintenance, or repair by anyone other than an Authorized retailer or Olight itself.

EU-DECLARATION OF CONFORMITY

EU-Declaration of Conformity can be found here CE:
https://olightworld.com/ec-declaration

USA Customer Support
cs@olightstore.com

Global Customer Support
customer-service@olightworld.com

Visit **www.olightworld.com** to see our complete product line of portable illumination tools.

Dongguan Olight E-Commerce Technology Co., Ltd
4th Floor, Building 4, Kegu Industrial Park, No 6 Zhongnan Road, Changan Town, Dongguan City, Guangdong, China.
Made in China

THANK YOU!